



PURPOSE

To centralize the tool string in large diameter tubing and casings.

ASSEMBLY PARTS

1. Fishneck
2. Mandrel
3. Spring
4. Spring Sub
5. Bow Spring
6. Bottom Sub

APPLICATION

Generally ran just above the pulling tool, but some applications may require multiple Centralizers higher in the tool string.

PRECAUTIONS

After each use, inspect bow springs for cracks and wear.

The mandrels are much lighter than full size tool string, so excessive jarring should be avoided.

Running through profile nipples will score the seal bore, thus damaging the nipple and plugs will not seal.

* Contact us for more information on our 1.50" Adjustable Centralizer *

Nominal Size		1.50"	1.75"
Assembly Number		0101C150A010	0101C175A010
Item	Part Name		
1	Fishneck	0101C15001	0101C17501
2	Mandrel	0101C15002	0101C17502
3	Spring	0101C15003	0101C15003
4	Spring Sub	0101C15004	0101C17504
5	Bow Spring	0101C15005	0101C15005
6	Bottom Sub	0101C15006	0101C17506
Upper Thread Connection		0.625" SR	0.75" SR
Lower Thread Connection		0.625" SR	0.75" SR
Max O.D.		7"	7"
Fishneck size		1.188"	1.375"