



PURPOSE

The Cam Cutter is used to cut slickline and wireline above the rope sockets when necessary.

ASSEMBLY PARTS

1. Drop Bar (18")
2. Drop Bar (30")
3. Drop Bar (60")
4. Body
5. Cutter Block
6. Cutter Wheel
7. Plunger

OPERATION

Attach to the line ensuring all internal parts are aligned. The two halves of the cam cutter must fit back together around the line properly and the pins are installed in the drop bar. Allow cutter to slide down the line until the rope socket is impacted which will shear the pins actuating the cutter wheel, snipping the line.

Nominal Size		1.62"
Assembly Number		0501CC162A0
Item	Part Name	
1	Drop Bar (18")	0501CC16201
2	Drop Bar (30")	0501CC16202
3	Drop Bar (60")	0501CC16203
4	Body	0501CC16102
5	Cutter Block	0501CC20003
6	Cutter Wheel	0501CC16104
	Plunger	0501CC16105
Top Thread Connection		1.062" – 10 UN
Max O.D.		1.62"
Fishneck size		1.375"
Max Line Size Cut		0.25"

*** Various size threaded guides for the drop bars are available upon request for use in larger size tubing and casing. ***