



## PURPOSE

The Fishing Clamp is used to hold or clamp wireline or slickline at the surface during fishing operations.

## ASSEMBLY PARTS

1. Top Plate
2. Bottom Plate
3. Insert
4. Allen Cap Screw
5. Flat Head Screw

## APPLICATION

The Round Line Clamp is used when there is a desire to lubricate broken line from the wellbore. The Round Line Clamp utilizes a 5/8" SR thread which allows the tool string to be drawn up inside the lubricator.

## OPERATION

Extract the allen cap screws from the top and bottom plates so the clamp be separated into two parts.

Ensure proper sized inserts are installed into the clamp before installing around the line.

Install around the line, ensuring the line is aligned in the centre of the inserts. Install the allen cap screws into the top and bottom plates and tighten. This will hold the line stationary.

**\*\* Please specify line size when ordering. \*\***

Nominal Size		Assembly Number	Insert
Item	Line Size		
3	0.092"	0501LCR231A0	0501LCR23104
3	0.108"	0501LCR231A2	0501LCF00005
3	0.125"	0501LCR231A3	0501LCF00006
3	0.140"	0501LCR231AA	0501LCF00007
3	0.150"	0501LCR231A3	0501LCF00008
3	0.160"	0501LCR231A4	0501LCF00009
3	0.187"	0501LCR231A5	0501LCF00010
3	0.218"	0501LCR231A6	0501LCF00011
3	0.250"	0501LCR231A7	0501LCF00012
3	0.312"	0501LCR231A8	0501LCF00013
3	0.375"	0501LCR231A9	0501LCF00014
1	Top Plate	0501LCR23101	n/a
2	Bottom Plate	0501LCR23102	n/a
4	Allen Head Cap Screw	0.50" – 13 UNC x 1"	n/a
5	Flat Head Screw	10-24 x 0.50"	n/a
Upper Thread Connection		0.938 – 10 UN	n/a