



PURPOSE

The No-Blow tool is a service tool that eliminates blowing gas and prevents pressure recorders from flowing up into the well bore. The tool comes into use during testing programs and in pipeline maintenance activities.

ASSEMBLY PARTS

1. Top Sub
2. Spring
3. End Cap
4. Shaft
5. Spring Retainer (x2)
6. Key Housing
7. Key
8. Cam

OPERATION

The No-Blow Tool is commonly ran in conjunction with a J Unlatching Head.

Attach the No-Blow Tool, as well as any accessories, to the tool string and lower carefully into the wellbore to desired depth. Set down on pre ran No-Go and J off using a J Unlatching Tool. Remove the tool string from the wellbore.

Nominal Size		1.00"	1.25"	1.50"
Assembly Number		1201NB100A0	1201NB125A0	1201NB150A0
Item	Part Name			
1	Top Sub	1201NB10001	1201NB10001	1201NB10001
2	Spring (x2)	1201NB10002	1201NB10002	1201NB10002
3	End Cap	1201NB10003	1201NB10003	1201NB10003
4	Shaft	1201NB10004	1201NB12504	1201NB15004
5	Spring Retainer (x2)	1201NB10005	1201NB10005	1201NB10005
6	Key Housing	1201NB10006	1201NB10006	1201NB10006
7	Key	1201NB10007	1201NB10007	1201NB10007
8	Cam	1201NB10008	1201NB12508	1201NB15008
Top Thread Connection		0.500" – 13 UNC	0.500" – 13 UNC	0.500" – 13 UNC
Lower Thread Connection		0.500" – 13 UNC	0.500" – 13 UNC	0.500" – 13 UNC
Tubing I.D		1.06"	1.40"	1.62"

(Sizes continue on next page)

Nominal Size		2.062"	2.00"	2.50"	3.00"
Assembly Number		1201NB206A0	1201NB237A0	1201NB287A0	1201NB350A0
Item	Part Name				
1	Top Sub	1201NB23701	1201NB23701	1201NB23701	1201NB23701
2	Spring (x2)	1201NB23702	1201NB23702	1201NB23702	1201NB23702
3	End Cap	1201NB23703	1201NB23703	1201NB23703	1201NB23703
4	Shaft	1201NB23704	1201NB23704	1201NB23704	1201NB35004
5	Spring Retainer (x2)	1201NB23705	1201NB23705	1201NB23705	1201NB23705
6	Key Housing	1201NB23706	1201NB23706	1201NB23706	1201NB23706
7	Key	1201NB20607	1201NB23707	1201NB28707	1201NB35007
8	Cam	1201NB23708	1201NB23708	1201NB28708	1201NB35008
Top Thread Connection		0.75" – 16 UNF	0.75" – 16 UNF	0.75" – 16 UNF	0.75" – 16 UNF
Lower Thread Connection		0.75" – 16 UNF	0.75" – 16 UNF	0.75" – 16 UNF	0.75" – 16 UNF
Max O.D. of Keys		1.80"	2.050"	2.50"	3.050"

Nominal Size		4.50"	5.00"	5.50"	7.00"
Assembly Number		1201NB450A0	1201NB450A0	1201NB550A0	1201NB700A0
Item	Part Name				
1	Top Sub	1201NB45001	1201NB45001	1201NB45001	1201NB70001
2	Spring (x2)	1201NB45002	1201NB45002	1201NB45002	1201NB70002
3	End Cap	1201NB45003	1201NB45003	1201NB45003	1201NB70003
4	Shaft	1201NB45004	1201NB45004	1201NB45004	1201NB70004
5	Spring Retainer (x2)	1201NB45005	1201NB45005	1201NB45005	1201NB70005
6	Key Housing	1201NB45006	1201NB45006	1201NB45006	1201NB70006
7	Key	1201NB45007	1201NB50007	1201NB55007	1201NB70007
8	Cam	1201NB45008	1201NB45008	1201NB45008	1201NB70008
Top Thread Connection		0.938" – 10 UN	0.938" – 10 UN	0.938" – 10 UN	0.938" – 10 UN
Lower Thread Connection		0.938" – 10 UN	0.938" – 10 UN	0.938" – 10 UN	0.938" – 10 UN
Max O.D. of Keys		4.25"	4.70"	5.00"	6.43"